

INSTALLATION INSTRUCTIONS

MONTAGEANLEITUNG

UV-Protection Yellow Foil self-adhesive

1. PREPARATION

For a successful installation we recommend the following **Lithoprotect®** articles:

	Name	Article Description	Article Number
01	Yellow foil self-adhesive	YSA 520	GESA520001
02	Seam tape	YST 520	GEZBDX520
03	Mounting fluid	DX MF 301	GEZBDX301
04	Plastic squeegee	DX RA 100	GEZBDX100

2. WINDOW CLEANING

Clean the window onto the **Lithoprotect® UV-Yellow Foil** is to be attached thoroughly with glass cleaner. Use a glass scraper or razor blade to remove all solid dirt from the glass. Now clean again the (windows) surface with the **Lithoprotect® DX MF 301 mounting fluid** to remove remnants of glass cleaner. Then dry the corners and edges with lint-free cloths. The glass surfaces must be absolutely free from silicone, be free of grease and dust.

3. FOIL CUTTING

Measure the desired surface exactly. Subtract 1-2 mm from the width and length so that the piece of **Lithoprotect® UV-Yellow Foil** is smaller than the surface to be covered when you apply the foil later. Now transfer the measurements to the foil and cut it to size. The red check pattern on the back of the foil helps to provide a rectangular orientation of the cut. After cutting, check by placing the foil on the surface to be covered whether the yellowfoil is 1-2 mm smaller all around than the area to be covered.

4. APPLYING MOUNTING FLUID DX MF 301

Spray the cleaned and still dry side of the pane very lightly and evenly from bottom to top with the **Lithoprotect® mounting fluid DX MF 301**. The glass should only be slightly damp, not dripping wet. Immediately before applying the **Lithoprotect® UV-Yellow Foil**, the pane can be moistened again.

5. PROTECTIVE FOIL REMOVAL

Now remove the red checkered protective foil covering the adhesive surface of the **Lithoprotect® UV-Yellow Foil** by attaching two "Scotch" strips on the upper outer corners of the foil.

NOTE: *Please do not touch the adhesive surface directly with your fingers. Fingerprints caused by this will remain visible in the adhesive after installation. The adhesive tape strips allow you to hold the foil and position it precisely.*

INSTALLATION INSTRUCTIONS

MONTAGEANLEITUNG

Hold the slide above at the two corners, while a second person withdraws the protective foil from a corner. Do not touch the dry adhesive side with your fingers. Be careful that neither lint nor dust attaches onto the adhesive surface.

TIP: *If it is necessary to touch the foil directly, we recommend moistening both the adhesive surface at the contact points and the fingers with our **Lithoprotect® DX MF 301** mounting fluid to reduce fingerprints.*

6. APPLYING THE FOIL

Now place the adhesive surface of the **Lithoprotect® UV-Yellow Foil** exactly on the damp pane surface. When applying the foil, avoid air bubbles between the foil and the window pane. Due to the foil of moisture between the foil and the window pane, the position of the foil can be carefully corrected again before pressing it on.

7. SQUEEZING OUT THE MOUNTING FLUID DX MF 301

Now carefully press the **Lithoprotect® UV-Yellow Foil** with the felt edge of the **Lithoprotect® DX RA 100** squeegee onto the center of the window. Hereby, proceed as follows: Move from the center starting up, then to the left and right continuously up until all moisture is squeezed out of the foil, and no air bubbles or wrinkles remain. If air bubbles are visible after applying the foil, push them to the edge of the foil with the felt edge while squeegeeing so that they can escape. Squeegee until all air bubbles and the foil of mounting fluid under the UV-foil are pressed out. Once the foil has been pressed on, it cannot be removed again.

Now wipe the edges of the foil dry and systematically press the foil down again with the felt edge of the **Lithoprotect® DX RA 100 squeegee**. Squeegee the foil dry, without any installation fluid. Excessive moisture can severely reduce the adhesive strength of the foil. Always keep the reverse side of the foil dry!

In the first few days after installation, the yellow foil may still appear slightly milky or streaky. This is normal during the drying process and will disappear as the residual moisture evaporates through the foil.

ATTENTION: *If possible, avoid applying the foil in extreme sunlight or frost. Please use only the felt edge of the **Lithoprotect® DX RA 100 squeegee** for pressing on, otherwise the foil may be scratched. The squeegee should be applied dry, without installation fluid.*

8. MASKING OF EDGE CONNECTIONS AND BUTT EDGES WITH SEAM TAPE YST20

After the **Lithoprotect® UV-Yellow Foil** has been successfully bonded, there is a gap of 1 to 2 mm all around the foil to adjoining seals or components. The circumferential gap is now sealed with **Lithoprotect® seam tape YST520**.

Please dry the area to be taped before applying **Lithoprotect® seam tape YST520**.

After removing the protective foil from the adhesive side, the seam tape is now applied dry and overlapping onto the yellow foil and the seal or adjacent components. Please seal all areas that are still translucent with the **Lithoprotect® seam tape YST520**.

INSTALLATION INSTRUCTIONS

MONTAGEANLEITUNG

THE SOLUTION FOR OVER LARGE GLASS SURFACES

If the surface to be covered with **Lithoprotect® seam tape YST520** is broader than the roll (which has a width of 115 cm), you can stitch two pieces of foil side by side and cover the abutting ends with our special **Lithoprotect® seam tape YST520**. With the **Lithoprotect® seam tape YST520** you can be sure, that no UV light will tunnel into your room. This **Lithoprotect® seam tape YST520** you can use as well for covering the edges between the foil and the window frame.

TIP: *Under the following link you can find a video tutorial for mounting our self-adhesive yellow foil:*
<https://www.youtube.com/watch?v=1va80t6G1C4>

Further Information

All data and information relate to the best of our knowledge and are based on measurement and experience. It remains in your responsibility to check the suitability of our yellow foil for the intended use of it. Our products are regularly quality-tested and further developed. We therefore reserve the right to adjust without additional information, the chemical composition or physical characteristics of new knowledge.

For any further information please contact our technical advisory.

Your request by E-Mail or Phone.

E-Mail: info@lithoprotect.com

Phone: +49 (0) 731 3608 0916

The brand **Lithoprotect®** belongs to:

durXtreme

durXtreme GmbH
Nicolaus-Otto-Str. 39
89079 Ulm
Germany